

Evolution 8

Delivery & Preparation Guide

- Base Preparation
- Access
- Electrical Requirements
- Considerations





Base Preparation

Your Evolution hot tub will require firm level area on which to sit. The base should be as level as possible – though small discrepancies for rainfall dispersal etc. are acceptable.

Concrete, existing patio, and decking (well supported) are typical choices. Grass is not acceptable as a hot tub base.

Note: The electrical cable **must not** feed through your chosen base/under the hot tub.

Site Location.

The exact location for your hot tub is subject to personal choice, however it is important your base/area should be of sufficient size to hold the footprint of the hot tub. It is also important to provide enough access (46cm) to the side/back to accommodate the cover (when folded back).

Access

Your hot tub will be delivered using a Spa Dolly delivery trailer, in most cases.

The Spa Dolly Kart then sits under the hot tub – allowing the spa to be wheeled into place easily.

The Evolution 8 requires the following dimensions:

Height: 237cm (93")

Width: 94cm (37")



32 AMP ELECTRICAL REQUIREMENTS

The Evolution 8 uses a 32-amp supply on 6mm SWA cable with RCD protection (cable sizes may be different depending on the length of cable run between the consumer unit and commando socket). A commando socket with local isolation is required between 1.5 meters and 3 metres of the spa, complete with 'male' plug and 8 metres of SY flex with UV protection or supply with flexible conduit). The flex is hard-wired to the spa by our engineers, then simply plugged in to complete.

A 32AMP dedicated electrical installation will typically cost around £300-£350 and typically take approximately two hours to complete.

* The commando socket supply DOES NOT require your electrician present on installation. However, a 32 amp 'hard-wired' supply WILL REQUIRE YOUR ELECTRICIAN PRESENT ON INSTALLATION to complete the wiring connection.

A new RCD circuit breaker must be used for your spa installation. Do not use an existing breaker, as its condition is unknown. The spa must be connected to a dedicated RCD breaker that is not shared with any other equipment. Do not use an extension or plug type cords of any kind.

The hot tub does not come with a plug and SY flex so please make sure this is supplied by your electrician.



Other Considerations

You'll need a hosepipe to fill your new hot tub.

If you have any questions about your preparation or access don't hesitate to call the team on 01253 599330.

